```
%image processing for PV measurment
%Donggeon Kim - u1419226
% Optical character recognition (OCR) from Vision toolbox of MATLAB is used
% Portions of this script were developed with the assistance of ChatGPT
 (OpenAI) and MATLAB documentation
% I= imread ('452.png');
% result = ocr(I, 'TextLayout', 'Line','characterSet','0123456789');
% outputNum=str2double(result.Text);
% My MP4 file from S25 uses the HEVC (H.265) codec, which is not supported by
MATLAB's VideoReader.
% MATLAB supports H.264 (AVC) but not HEVC.
% Typing at this in WSL terminal -> ffmpeg -i example_30.mp4 -vcodec libx264 -
acodec aac example_30_converted.mp4
% Define paths
videoFile = 'C:\Users\jsks12312\Desktop\PV_measurement\image_processing
\example_30_converted.mp4';
% Extract video name without extension to create a folder
[~, videoName, ~] = fileparts(videoFile);
outputFolder = fullfile('C:\Users\jsks12312\Desktop\PV_measurement
\image_processing\', videoName);
% Create output directory if it doesn't exist
if ~exist(outputFolder, 'dir')
    mkdir(outputFolder);
end
% Get current date in YYYY_MM_DD format (initialized before filenames are
used)
currentDate = datestr(now, 'yyyy_mm_dd');
% Initialize extracted data structure before the loop
extractedData = struct('Time', {}, 'ExtractedText', {}, 'ImageFile', {});
% Open the video file
video = VideoReader(videoFile);
% Get the total duration of the video
videoDuration = min(10, video.Duration); % Process only up to 10 sec
% Create a file to save extracted OCR results in the same folder
ocrResultsFile = fullfile(outputFolder, sprintf('%s
%s_Extracted_OCR_Results.txt', currentDate, videoName));
fileID = fopen(ocrResultsFile, 'w'); % Overwrite previous results
fprintf(fileID, 'Time (s)\tExtracted Text\n');
% Define capture interval within each second (±0.1s around the target time)
captureOffset = 0.1;
```

```
% Iterate over the video from 0 to 10 seconds
for targetTime = 0:1:videoDuration % Iterate at 1s intervals
    % Generate timestamps, ensuring no negative values
    timeStamps = max(0, [targetTime - captureOffset, targetTime, targetTime +
 captureOffset]);
    % Iterate over the three timestamps per second (0.0s, 0.1s, 0.2s, etc.)
    for i = 1:length(timeStamps)
        % Set the video to the desired timestamp
       video.CurrentTime = timeStamps(i);
        if hasFrame(video)
            frame = readFrame(video);
            % Convert seconds to HH_MM_SS_MMM format (precise video time with
 milliseconds)
            totalMilliseconds = round(video.CurrentTime * 1000); % Convert
 seconds to milliseconds
            hours = floor(totalMilliseconds / (3600 * 1000));
            minutes = floor(mod(totalMilliseconds, (3600 * 1000)) / (60 *
 1000));
            seconds = floor(mod(totalMilliseconds, (60 * 1000)) / 1000);
            milliseconds = mod(totalMilliseconds, 1000);
            % Format timestamp as "05h 20m 02s 100ms"
            % to meet the format
            timeStr = sprintf('%02dh_%02dm_%02ds_%03dms', hours, minutes,
 seconds, milliseconds);
            % save full frame inside the video-named folder for
            % organization
            frameFilename = fullfile(outputFolder, sprintf('%s_%s_frame_
%s.png', currentDate, videoName, timeStr));
            imwrite(frame, frameFilename);
            disp(['Saved full frame at ',
 num2str(video.CurrentTime, '%.3f'), ' sec as ', frameFilename]);
            % Convert to grayscale and preprocess to help image
            % recogniztion
            grayFrame = rqb2qray(frame);
            grayFrame = imadjust(grayFrame, [0.3, 0.7], [0, 1]); % enhance
 contrast
            grayFrame = medfilt2(grayFrame, [3, 3]); % Reduce noise
            % select region of interest from images
            if targetTime == 0 && i == 1 % Only ask for ROI once
                figure, imshow(frame);
                title('Select ROI for Multimeter Display');
                roi = round(getrect); % User selects ROI
                disp(['Selected ROI: ', num2str(roi)]);
            end
            % Crop the frame to the ROI - it works at being saved at
```

```
% desired location
            croppedFrame = imcrop(grayFrame, roi);
            % Save cropped frame in the same folder with precise timestamp
            croppedFilename = fullfile(outputFolder, sprintf('%s_%s_cropped_
%s.png', currentDate, videoName, timeStr));
            imwrite(croppedFrame, croppedFilename);
            disp(['Saved cropped image at ',
num2str(video.CurrentTime, '%.3f'), ' sec as ', croppedFilename]);
%failing point
            % apply OCR to the cropped frame
            result = ocr(croppedFrame, 'CharacterSet', '0123456789.-');
            extractedText = strtrim(result.Text);
            % display extracted text on terminal
            disp(['Extracted Text at ', num2str(video.CurrentTime, '%.3f'), '
 sec: ', extractedText]);
            % save extracted text to file
            fprintf(fileID, '%.3f\t%s\n', video.CurrentTime, extractedText);
            % Store extracted data
            extractedData(end+1) = struct( ...
                'Time', video.CurrentTime, ...
                'ExtractedText', extractedText, ...
                'ImageFile', croppedFilename);
        end
    end
end
% Close results file
fclose(fileID);
% Convert extracted data to a table and display in MATLAB
% it needs work
if ~isempty(extractedData)
    extractedTable = struct2table(extractedData);
    disp(extractedTable);
    % Save extracted data to CSV in the same folder
    csvFilename = fullfile(outputFolder, sprintf('%s
%s_Extracted_OCR_Data.csv', currentDate, videoName));
    writetable(extractedTable, csvFilename);
    disp(['OCR results saved to ', csvFilename]);
else
    disp('No text was extracted from the video.');
end
disp('OCR Processing Complete.');
Saved full frame at 0.033 sec as C:\Users\jsks12312\Desktop
\PV measurement\image processing\example 30 converted
\2025_03_22_example_30_converted_frame_00h_00m_00s_033ms.png
```

Published with MATLAB® R2021b